

CONNECTIONS UPHOLSTERY ASSEMBLY INSTRUCTIONS

Our Connections style upholstery can be easily assembled without any tools. Please follow the directions below.

1. Remove and unwrap all the components and the hardware bag. You should have the following:
 - a. 2 arms (with 2 feet per arm)
 - b. 1 seat frame
 - c. 1 back frame
 - d. Seat & Back cushions (quantity depends on chair, loveseat or sofa)
 - e. 3 prong knobs and washers (quantity depends on chair, loveseat or sofa)
2. Turn seat frame so front side is on the floor. Note: The back side has drilled holes at edge of frame
3. Attach the arms by inserting the pre-installed bolts through the matching holes in the seat frame. Make sure the metal "keyslot" bracket is located at the back of seat frame. From the underside of seat frame use (2) washers and (2) 3 prong knobs to loosely attach each arm to frame. Do not tighten knobs completely at this point.
4. Turn the seat frame and 2 arm assembly upright. Align the metal button studs on sides of back frame with the keyslot brackets on inside of each arm. Then be sure that the preinstalled bolts at bottom of back frame are aligned with holes in seat frame. Once aligned, gently push down on back to set it into the keyslots.
5. Turns assembly onto front edge, reach underneath and attach back with washers and 3 prong knobs. Tighten all the 3 prong knobs, including the ones that secure the arms.
6. Attach wood feet to arms if not already in place. Locate threaded holes in each arm at front and back. Screw in foot until snug with arm frame. Align sides of feet with sides of arms
7. Turn the piece onto its feet and install seat and back cushions

Assembly is complete. It is a good idea to re-tighten the knobs every month.



3 Prong knob & washer



Keyslot Bracket



Chair with one arm



Chair with 2 arms



Assembled chair with arms and back



Chair complete with seat & back cushions